

SCHEDULE OF SPARE PARTS FOR CS 299

| Qty | CODE | DESIGNATION | Qty | CODE | DESIGNATION | Qty | CODE | DESIGNATION |
|-----|-------|-----------------------------------|-----|-------|--|-----|-------|--|
| 2 | Z4 | Backstop spring | 1 | Z897 | Bottom stop (France) | 2 | Z3475 | Air tube 2.7 x 4 white L=155 mm |
| 1 | Z6 | Limit switch spring | 1 | Z900 | Wedge insertion stop nut | 2 | Z3476 | Air tube 2.7 x 4 white L=550 mm |
| 1 | Z14 | Short preclamping spring MS747 | 1 | Z901 | End of travel stop support | 1 | Z3478 | Air tube 2.7 x 4 white L=710 mm |
| 1 | Z15 | Long preclamping spring MS 332 | 1 | Z902 | Hammer support washer | 2 | Z3480 | Air tube 2.7 x 4 white L=775 mm |
| 1 | Z17 | Sliding clamping shoe spring | 2 | Z923 | Spring 20515095C | 2 | Z3481 | Air tube 6 x 8 white L=55 mm |
| 1 | Z29 | Multiple connection 6 - 4 | 1 | Z928 | Straight connection Ø 4-1/4" | 1 | Z3482 | Air tube 6 x 8 white L=460 mm |
| 2 | Z96 | Adaptor spring | 1 | Z947 | Pressure gauge + strap M. 1/8" | 2 | Z3483 | Air tube 2.5 x 4 blue L=340 mm |
| 4 | Z97 | Locking screw | 1 | Z967 | Toe | 2 | Z3484 | Air tube 2.5 x 4 blue L=550 mm |
| 1 | Z99 | Angle adjustment screw | 1 | Z1052 | Cylinder Ø 85 C: 80 | 2 | Z3485 | Air tube 2.5 x 4 blue L=605 mm |
| 1 | Z100 | Screw backstop | 2 | Z1097 | Straight connection Ø 8-1/4" | 1 | Z3486 | Air tube 2.5 x 4 blue L=910 mm |
| 1 | Z102 | Backstop spacer | 1 | Z1113 | Press plunger | 1 | Z3487 | Air tube 4x6 blue L=50 mm |
| 1 | Z103 | Washer | 1 | Z1114 | Return spring | 1 | Z3488 | Air tube 4x6 blue L=155 mm |
| 2 | Z106 | Porter | 1 | Z1251 | Sliding clamping shoe | 1 | Z3537 | Bottom metal sheet |
| 2 | Z130 | Cam | 1 | Z1252 | Adjusting gib | 1 | Z3538 | Top presser storage |
| 2 | Z140 | Pivoting clamping shoe washer | 1 | Z1254 | Pivoting clamping shoe | 1 | Z3539 | Air tube 2.7 x 4 red L=620 mm |
| 2 | Z195 | "MITEM" button spacer | 8 | Z1352 | Elbow Ø 4-1/8" | 1 | Z3540 | Air tube 2.7 x 4 red L=965 mm |
| 1 | Z257 | Reduction M8-4 F | 1 | Z1385 | Pneumatic indicator (green) | 1 | Z3541 | Air tube 2.5x4 red/white L=2200 mm |
| 2 | Z295 | Stop label | 1 | Z1394 | Pusher with ball M5 | 1 | Z3601 | Nylon wire Ø 1,3mm (Lg: 6,5 mm) |
| 1 | Z420 | Wedge pusher spring | 1 | Z1406 | Pedal | 1 | Z4079 | Clamping cylinder frame |
| 1 | Z422 | Axle for cartridge pusher spring | 1 | Z1459 | Limit switch | 1 | Z4258 | Door |
| 3 | Z469 | Straight connection Ø 4-1/8" | 1 | Z1461 | Preclamping sensor | 8 | Z4308 | Insert nut HU M12 |
| 1 | Z506 | Hammer | 3 | Z1479 | Elbow Ø4 - 1/4" | 4 | Z4857 | Base footing |
| 1 | Z578 | Rear bar | 1 | Z1499 | Elbow Ø6 - 1/4" | | | |
| 1 | Z581 | Front bar | 4 | Z1575 | Door hinge | | | |
| 1 | Z586 | Pivoting clamping shoe spring | 2 | Z1593 | Washer | 2 | Z433 | MITEM button assy |
| 1 | Z587 | Clamping shoe axis | 1 | Z1596 | 1/8" sleeve | 1 | Z446 | Wedge pusher spring assy |
| 1 | Z588 | Clamping shoe lever | 1 | Z1617 | Cable cover | 1 | Z634 | Wire with ball assy |
| 1 | Z589 | Clamping shoe thrust bearing | 1 | Z1663 | Door knob ball Ø20 M6 F | 1 | Z644 | Sliding table assy |
| 1 | Z594 | Lever holder | 1 | Z1688 | Seale 0 - 500 | 1 | Z645 | Air supply valve assy |
| 1 | Z595 | Lever | 1 | Z1813 | White top presser triangle | 1 | Z816 | Triangle support + screw assy |
| 1 | Z596 | Rod | 1 | Z1814 | Black top presser triangle | 1 | Z817 | Wedge distributor with square guide |
| 1 | Z598 | Backstop holder plate | 1 | Z1840 | T connection Ø 8 | 1 | Z829 | Wedge distributor without square guide |
| 1 | Z599 | Right backstop holder | 2 | Z1853 | Cap 1/4" | 1 | Z887 | Adjustable triangle assy |
| 1 | Z600 | Right backstop | 4 | Z1876 | Silencer 1/4" | 1 | Z909 | Hammer support assy |
| 1 | Z601 | Left backstop holder | 3 | Z1930 | Female Y Ø 4 | 1 | Z1130 | Retractable toe assy |
| 1 | Z602 | Left backstop | 1 | Z2753 | Rubber protection of knob | 1 | Z1136 | Set of main plates assy |
| 1 | Z603 | Backstop guide plate | 1 | Z3177 | Machined air cylinder | 1 | Z1141 | Loader support assy |
| 1 | Z604 | Adjusting gib | 1 | Z3180 | Spacer | 1 | Z3078 | Spacer bars assy |
| 1 | Z612 | Indexing backstop guiding rod | 1 | Z3184 | Handle | 2 | Z3376 | Clamp bearing assy |
| 1 | Z620 | Indexing backstop AC | 1 | Z3185 | Switch support | 1 | Z3384 | Sleeve assy |
| 1 | Z621 | Clamping shoe adjustment screw | 1 | Z3190 | Air distributor 5/2 with simple pusher | 1 | Z3491 | Sliding table handle assy |
| 1 | Z626 | Indexing backstop AB | 1 | Z3195 | Clamping shoe frame | 1 | Z3492 | Sliding table stop assy |
| 1 | Z629 | Door latch | 2 | Z3197 | Metal column | 1 | Z3498 | Fixed stop assy |
| 1 | Z675 | Q/R air connector M. 1/4" | 1 | Z3198 | Air distributor door | 1 | Z3499 | Adjustable stop assy |
| 1 | Z701 | Q/R air connector M. 1/4" (US) | 1 | Z3217 | Contact support spacer | 1 | Z3648 | Stapling bar assy |
| 1 | Z710 | Q/R air connector M. 1/4" (Japan) | 1 | Z3388 | Stapling stop | 1 | Z3652 | Handle assy |
| 1 | Z759 | Fixed guide | 1 | Z3430 | Frame | 1 | Z3653 | Stapling command rod assy |
| 1 | Z851 | Circuit selector 1/4" | 1 | Z3473 | Shell | 1 | Z3654 | Air exhaust assy |
| 2 | Z855 | Air distributor 5/2 | 4 | Z1589 | Washer | 1 | Z3655 | Loader assy |
| 4 | Z1338 | Nut | 1 | Z3474 | Air tube 2.7 x 4 white L=50 mm | 1 | Z3673 | Air regulator assy |